

DTC P0638:00	Throttle valve actuator control range/performance problem
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM compares the actual TP with the target TP. If the difference is more than the threshold value, the PCM determines that there is a throttle valve actuator control range/performance problem. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Restricts the upper limit of the engine speed. Stops the drive-by-wire control (throttle valve is open at approx. 8 ° by return spring force).
POSSIBLE CAUSE	<ul style="list-style-type: none"> Throttle body connector or terminals malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> Throttle body terminal E—PCM terminal 1CG Throttle body terminal F—PCM terminal 1CC PCM connector or terminals malfunction Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> Throttle body terminal E—PCM terminal 1CG Throttle body terminal F—PCM terminal 1CC Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Throttle body terminal E—PCM terminal 1CG Throttle body terminal F—PCM terminal 1CC Throttle valve actuator malfunction Throttle valve malfunction PCM malfunction

⑨

THROTTLE VALVE ACTUATOR
(THROTTLE BODY)

THROTTLE BODY
WIRING HARNESS-SIDE
CONNECTOR

PCM

PCM WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition to off, then to ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	Go to the next step.
4	INSPECT THROTTLE BODY CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the throttle body connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
5	INSPECT THROTTLE VALVE ACTUATOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the throttle body connector is disconnected. Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> Throttle body terminal E Throttle body terminal F Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 10.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
7	INSPECT THROTTLE VALVE ACTUATOR CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the throttle body and PCM connectors are disconnected. Switch the ignition ON (engine off or on). Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> Throttle body terminal E—PCM terminal 1CG Throttle body terminal F—PCM terminal 1CC Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 10.
8	INSPECT THROTTLE VALVE ACTUATOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the throttle body and PCM connectors are disconnected. Switch the ignition to off. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> Throttle body terminal E—PCM terminal 1CG Throttle body terminal F—PCM terminal 1CC Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 10.

STEP	INSPECTION	ACTION	
9	INSPECT THROTTLE VALVE <ul style="list-style-type: none"> • Perform the Electronic Control Throttle Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the throttle body, then go to the next step. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
10	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Start the engine. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.