

LIGHTING SYSTEM PERSONALIZATION

id091800013300

- A personalization function has been adopted with which settings for each function can be changed.

Turn Light System

Using Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
3-Flash Turn Signal.	The turn light system can be switched between operable and inoperable.	ON	Not Adopted. / OFF / ON	Rear body control module (RBCM)

Using audio unit (with color LCD)

Audio unit display	Function	Initial setting	Setting contents	Control module
3-Flash Turn Signal	The turn light system can be switched between operable and inoperable.	On	On / Off	Rear body control module (RBCM)

Auto Light System

Using Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
Auto-headlight On.	Auto light sensor sensitivity can be changed.	Medium	Not Adopted. / Dark / Medium Dark / Medium / Medium Light / Light	Rear body control module (RBCM)

Using audio unit (with color LCD)

Audio unit display	Function	Initial setting	Setting contents	Control module
Auto-headlight On	Auto light sensor sensitivity can be changed.	Medium	Light / Medium Light / Medium / Medium Dark / Dark	Rear body control module (RBCM)

- Auto light sensitivity setting illuminates/turns off the headlights (LO) and TNS according to the following illumination level.

Note

- The following illumination level is a reference. It varies depending on conditions in the surrounding area (weather, reflection off buildings).

Setting contents	Illumination operation		Lights off operation	
	TNS ON		TNS OFF	
	Headlights (LO) ON		Headlights (LO) OFF	
Light	4000 lux		8000 lux	
Medium Light	3000 lux		6000 lux	
Medium	2000 lux		4000 lux	
Medium Dark	1000 lux		2000 lux	
Dark	500 lux		1000 lux	

High Beam Control (HBC) System

Using Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
High Beam Control.	The high beam control (HBC) system can be switched between operable and inoperable.	ON	Not Adopted. / OFF / ON	Forward sensing camera (FSC)

Using audio unit (with color LCD)

Audio unit display	Function	Initial setting	Setting contents	Control module
High Beam Control	The high beam control (HBC) system can be switched between operable and inoperable.	On	On / Off	Forward sensing camera (FSC)

Room Light Control System

Using Mazda Modular Diagnostic System (M-MDS)

Mazda Modular Diagnostic System (M-MDS) display	Function	Initial setting	Setting contents	Control module
Interior Light Timeout-Door Open.	The front/rear map light illumination time after any door is open can be changed.	30 minutes.	Not Adopted. / 30 minutes. / 60 minutes. / 10 minutes.	Rear body control module (RBCM)
Interior Light Timeout-Door Closed.	The front/rear map light illumination time after any door is closed can be changed.	15 seconds.	Not Adopted. / 15 seconds. / 7.5 seconds. / 30 seconds. / 60 seconds.	Rear body control module (RBCM)

Using audio unit (with color LCD)

Audio unit display	Function	Initial setting	Setting contents	Control module
Interior Light Timeout - Door Open	The front/rear map light illumination time after any door is open can be changed.	30 minutes	60 minutes / 30 minutes / 10 minutes	Rear body control module (RBCM)
Interior Light Timeout - Door Closed	The front/rear map light illumination time after any door is closed can be changed.	15 seconds	60 seconds / 30 seconds/15 seconds / 7.5 seconds	Rear body control module (RBCM)

Running Light System

Note

- Refer to the workshop manual for the detailed setting procedure.

Function	Initial setting	Setting contents	Control unit
The running light system function can be set.	ON (running light illumination)	OFF (running light non-illumination)/ON (running light illumination)	Front body control module (FBCM)