


## OIL JET VALVE INSPECTION

id011000505900

1. Apply compressed air to oil jet valve A and verify that air passes through oil jet valve B.
  - If air does not flow, replace the oil jet valve.
  - If there is air flow with air compressor of less than **180 kPa {1.84 kgf/cm<sup>2</sup>, 26.1 psi}**, replace the oil jet valve.

### Oil jet valve opening pressure

**180—220 kPa {1.84—2.24 kgf/cm<sup>2</sup>, 26.2—31.9 psi}**



bp31je00000131