


DTC P0672:00	Glow plug No.2 control circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"> • If the input voltage is below 5 V for 5 s, the PCM determines that the glow plug No.2 circuit problem. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> — Battery voltage: 8—20 V — Detects that the output duty value of the glow plug is 10 to 90 % for 1 s or more. <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Glow plug No.2 connector or terminals malfunction • Glow control module connector or terminals malfunction • Open circuit in wiring harness between glow plug No.2 terminal B and glow control module terminal 1F • Short to ground in wiring harness between glow plug No.2 terminal B and glow control module terminal 1F • Short to power supply in wiring harness between glow plug No.2 terminal B and glow control module terminal 1F • PCM connector or terminals malfunction • Glow plug No.2 malfunction • Glow control module malfunction • PCM malfunction



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT GLOW PLUG NO.2 CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the glow plug No.2 connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
4	INSPECT GLOW CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the glow control module connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
5	INSPECT GLOW PLUG NO.2 CONTROL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the glow plug No.2 and glow control module connectors are disconnected. Inspect for continuity between glow plug No.2 terminal B (wiring harness-side) and glow control module terminal 1F (wiring harness-side). Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 11.
6	INSPECT GLOW PLUG NO.2 CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the glow plug No.2 and glow control module connectors are disconnected. Inspect for continuity between glow plug No.2 terminal B (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 11.
		No	Go to the next step.
7	INSPECT GLOW PLUG NO.2 CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the glow plug No.2 and glow control module connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the glow plug No.2 terminal B (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 11.
8	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
9	INSPECT GLOW PLUG NO.2 <ul style="list-style-type: none"> Inspect the glow plug No.2. (See GLOW PLUG INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the glow plug No.2, then go to Step 11. (See GLOW PLUG REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
10	INSPECT GLOW CONTROL MODULE <ul style="list-style-type: none"> Inspect the glow control module. (See GLOW PLUG CONTROL MODULE REMOVAL/ INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the glow control module, then go to the next step. (See GLOW PLUG CONTROL MODULE REMOVAL/ INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
11	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
12	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.