

ENGINE OIL PRESSURE SENSOR [SKYACTIV-D 2.2]


id0140z7257000

Purpose/Function

- Detects the engine oil pressure as basic information for mainly intake stroke EGR using double exhaust valve actuation system (IDEVA) control and idle speed control.
- Detects the engine oil pressure and sends it to the PCM as an engine oil pressure signal.

Construction


- Built into the engine oil temperature sensor/engine oil pressure sensor.
- A semiconductor gauge has been adopted to the engine oil pressure sensor as the detecting element for detecting the engine oil pressure.



ac5wzn00002481


Operation

- Sends the signal, which fluctuates according to the engine oil pressure, to the PCM.



ac5wzn00002482

Engine oil pressure sensor characteristic



ac5wzn00001656

Fail-safe

DTC No.	Fail-safe function
P0522:00	<ul style="list-style-type: none">• PCM restricts engine torque.• The fast idle up correction for the idle speed control is inhibited.• Inhibits engine-stop by operating the i-stop function.
P0523:00	<ul style="list-style-type: none">• PCM restricts engine torque.• The fast idle up correction for the idle speed control is inhibited.• Inhibits engine-stop by operating the i-stop function.