
ROLLOVER VALVE INSPECTION [SKYACTIV-D 2.2]

id0116e1804500

Note

- The rollover valve cannot be disassembled and inspected as it is built into the fuel tank.

1. Perform the fuel tank inspection. (See FUEL TANK INSPECTION [SKYACTIV-D 2.2].)
 - If there is any malfunction, replace the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)