
SYMPTOM TROUBLESHOOTING CHART [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR ALL WINDOWS)]

id0903608056j6

No.	Troubleshooting item	page
1	Door glass does not move up and down in automatic mode	(See DOOR GLASS DOES NOT MOVE UP AND DOWN IN AUTOMATIC MODE [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR ALL WINDOWS)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)].)
2	Door glass does not reverse, even when encountering a foreign object in its path	(See DOOR GLASS DOES NOT REVERSE, EVEN WHEN ENCOUNTERING A FOREIGN OBJECT IN ITS PATH [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR ALL WINDOWS)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)].)
3	Door glass reverses even though the glass does not encounter a foreign object while it is moving up in automatic mode	(See DOOR GLASS REVERSES EVEN THOUGH THE GLASS DOES NOT ENCOUNTER A FOREIGN OBJECT WHILE IT IS MOVING UP IN AUTOMATIC MODE [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR ALL WINDOWS)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)].)
4	Abnormal noise during the power window operation	(See ABNORMAL NOISE WHILE THE DOOR GLASS IS OPENING OR CLOSING [POWER WINDOW SYSTEMS (WITH AUTO-OPEN/CLOSE FUNCTION FOR ALL WINDOWS)] [POWER WINDOW SYSTEMS (AUTO-OPEN/CLOSE FUNCTION)].)