

## NO.1 ELECTRIC POWER STEERING (EPS) WARNING LIGHT DOES NOT ILLUMINATE WITH IGNITION SWITCHED ON

id060300950600

|   |  |
|---|--|
| 1   | <b>Electric power steering (EPS) warning light does not illuminate with ignition switched ON.*</b> |
| <b>TROUBLESHOOTING HINTS</b> <ul style="list-style-type: none"><li>• EPS warning light circuit malfunction in the instrument cluster.</li><li>• An error originates from the EPS CM, and the off signal is generated.<ul style="list-style-type: none"><li>— EPS CM malfunction</li></ul></li></ul> |  |

\* : Instrument cluster without TFT LCD display.

### Diagnostic procedure

| STEP | INSPECTION  |     | ACTION   |
|------|---|-----|--|
| 1    | <ul style="list-style-type: none"><li>• Turn on the EPS warning light at instrument cluster using the "WL+IL" of the M-MDS active command modes function.</li><li>• Does the EPS warning light turn on?</li></ul> | Yes | EPS CM malfunction. Replace the EPS CM.<br>(See STEERING GEAR AND LINKAGE REMOVAL/INSTALLATION.)   |
|      |   | No  | Perform the instrument cluster configuration, then repeat the inspection from Step 1.<br>(See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)<br>If the malfunction recurs, replace the instrument cluster.<br>(See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.) |