
AIR CLEANER ELEMENT INSPECTION [SKYACTIV-G 2.0]

id0113z5800800

1. Remove the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
2. Inspect the following items:
 - Has the replacement interval past?
 - Is the air cleaner element soiled, damaged, or bent?
 - Are the air cleaner case and the air cleaner element correctly sealed?
 - Is the correct air cleaner element installed?
 - If there is any abnormality, clean or replace the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)