

## FUEL FEED VALVE [SKYACTIV-D 2.2]


id0114z7707700

### Purpose, Function

- When the pressure in the lower case decreases, fuel from the supply pump is introduced to the lower case.


### Construction

- The fuel feed valve is integrated with the lower case.



ac5wzn00000200


- The fuel feed valve consists of the spring, ball and filter.



ac5wzn00000201

## Operation

- When the pressure in the lower case decreases to a certain value, the fuel from the supply pump flows into the lower case (on fuel injector side) by the ball pressing the spring.



ac5wzn00002618