

DTC P0604:00 [SKYACTIV-G 2.0]

id0102h1705800

DTC P0604:00	PCM RAM error
DETECTION CONDITION	<ul style="list-style-type: none"> • PCM internal RAM malfunction. Diagnostic support note <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • Restricts the upper limit of the engine speed. • Stops the drive-by-wire control (throttle valve is open at approx. 8 ° by return spring force).
POSSIBLE CAUSE	<ul style="list-style-type: none"> • PCM connector or terminals malfunction • PCM internal RAM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes Repair or replace the connector and/or terminals, then go to the next step.
		No Go to the next step.
4	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Start the engine. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No Go to the next step.
5	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No DTC troubleshooting completed.