

DOOR LOCK SWITCH INSPECTION

id091400518700

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
2. Remove the door lock switch. (See POWER WINDOW MAIN SWITCH REMOVAL/INSTALLATION.)
3. Verify that the continuity is as indicated in the table.

○—○ : Continuity ○○ : Resistance

Position	Terminal	
	2A	1E
Lock		
Unlock		

R: 950—1,050 ohms

ac5wzw00004588

- If the continuity is not as indicated in the table, replace the door lock switch.

