

TRANSFER OIL INSPECTION [C66MX-R, D66MX-R]

id0316g5800200

1. Park the vehicle on level ground.
2. Remove the oil level plug and with the washer.
3. Checking by hand, verify that the oil is near the brim of the plug hole.
 - If the oil level is low, add the specified amount and type of oil through the oil level plug hole.

Transfer oil

Specified oil grade: API Service GL-5

Specified oil viscosity: SAE 80W-90

Capacity (approx quantity): 0.45 L {0.48 US qt, 0.40 Imp qt}

4. Tighten the oil level plug with a new washer.

Tightening torque

40—58 N·m {4.1—5.9 kgf·m, 30—42 ft·lbf}

