
RAIN SENSOR INITIALIZATION SETTING

id091900810100

Note

- When the ignition is switched ON (engine off or on), the rain sensor detects the condition of the windshield surface, and performs initialization automatically.