

DTC P0607:00 [SKYACTIV-D 2.2]

id0102s4850500

DTC P0607:00	Control module performance problem
DETECTION CONDITION	<ul style="list-style-type: none">• PCM internal malfunction. MONITORING CONDITIONS <ul style="list-style-type: none">— Battery voltage: above 10 V Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (CCM).• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Inhibits engine-stop by operating the i-stop function.• PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none">• PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none">• Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none">• Verify related Service Information availability.• Is any related Service Information available?	Yes Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none">• If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none">• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].)• Is the same DTC present?	Yes Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No Go to the next step.
4	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none">• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)• Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No DTC troubleshooting completed.