

DTC P061F:00 [SKYACTIV-G 2.0]

id0102h1302600

DTC P061F:00	Internal control module throttle valve actuator controller performance problem
DETECTION CONDITION	<ul style="list-style-type: none"> When any of the following conditions is met: <ul style="list-style-type: none"> CAN communication line between start stop unit and PCM malfunction Start stop unit internal malfunction PCM internal malfunction Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	Note <ul style="list-style-type: none"> This DTC is an informational DTC and may be set in combination with a number of other DTCs which are causing the FMEM. Diagnose other DTCs first. <ul style="list-style-type: none"> CAN communication line between start stop unit and PCM malfunction Start stop unit connector or terminals malfunction PCM connector or terminals malfunction Start stop unit malfunction PCM malfunction
SYSTEM WIRING DIAGRAM	—

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
2	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition to off, then to ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Are any other PENDING CODEs and/or DTCs present? 	Yes Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No Go to the next step.
3	INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the start stop unit connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes Repair or replace the connector and/or terminals, then go to Step 5.
		No Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes Repair or replace the connector and/or terminals, then go to the next step.
		No Reconnect the PCM connector and verify that the connector seat correctly, then go to the next step.

STEP	INSPECTION	ACTION	
5	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none">• Make sure to reconnect all disconnected connectors.• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].)• Is the same DTC present?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
6	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none">• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].)• Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.