







DTC C0061:28/C0061:64/C0062:28/C0062:64/C0063:28/C0063:64 [DYNAMIC STABILITY CONTROL (DSC)]

id0402b2180800

DTC	C0061:28, C0061:64, C0062:28, C0062:64, C0063:28, C0063:64	SAS control module system
DETECTION CONDITION	<p>Note</p> <ul style="list-style-type: none"> The low-G sensor and the yaw rate sensor are built into the SAS control module. <ul style="list-style-type: none"> C0061:28, C0061:64 <ul style="list-style-type: none"> Out-of-specification signal modulation or lateral-G value is detected from the low-G sensor. C0062:28, C0062:64 <ul style="list-style-type: none"> Out-of-specification signal modulation or longitudinal-G value is detected from the low-G sensor. C0063:28, C0063:64 <ul style="list-style-type: none"> Out-of-specification signal modulation or yaw rate value is detected from the yaw rate sensor. 	
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> C0061:28, C0061:64, C0063:28, C0063:64 <ul style="list-style-type: none"> Illuminates the TCS/DSC indicator light and master warning light^{*1}. Tire pressure monitoring system warning light illuminates after flashes. Inhibits the TCS, DSC, roll over mitigation (ROM), TPMS, smart city brake support (SCBS)^{*1}, and secondary collision reduction (SCR) controls. C0062:28, C0062:64 <ul style="list-style-type: none"> Illuminates the ABS warning light^{*2}, TCS/DSC indicator light, and master warning light^{*1*2}. Inhibits the ABS^{*3}, TCS^{*3}, DSC^{*3}, roll over mitigation (ROM)^{*3}, brake assist control^{*3}, vehicle roll prevention function^{*4}, hill launch assist (HLA), smart city brake support (SCBS)^{*1*3}, and secondary collision reduction (SCR)^{*3} controls. <p>^{*1}: Vehicles with smart city brake support (SCBS) ^{*2}: Not illuminated depending on malfunction content. ^{*3}: Enabled depending on malfunction content. ^{*4}: ATX only</p>	
POSSIBLE CAUSE	<ul style="list-style-type: none"> SAS control module malfunction Open or short circuit in the CAN2_H wiring harness between DSC HU/CM terminal S and SAS control module terminal 3H Open or short circuit in the CAN2_L wiring harness between DSC HU/CM terminal P and SAS control module terminal 3I DSC HU/CM malfunction Poor connection at connectors (female terminal) 	
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>DSC HU/CM</p>  </div> <div style="text-align: center;"> <p>SAS CONTROL MODULE</p>  </div> </div> <p style="text-align: center; margin-top: 10px;">CAN2_H CAN2_L</p> <div style="display: flex; justify-content: space-around; align-items: flex-start; margin-top: 20px;"> <div style="text-align: center;"> <p>DSC HU/CM WIRING HARNESS-SIDE CONNECTOR</p>  </div> <div style="text-align: center;"> <p>SAS CONTROL MODULE WIRING HARNESS-SIDE CONNECTOR</p>  </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 20px;">   </div>		

Diagnostic procedure

STEP	INSPECTION		ACTION
1	INSPECT SAS CONTROL MODULE MALFUNCTION <ul style="list-style-type: none"> Switch the ignition to off. Using the M-MDS, perform the DTC inspection for the SAS control module. (See DTC INSPECTION.) Are any DTCs detected? 	Yes	Go to applicable DTC inspection. (See DTC TABLE.)
		No	Go to the next step.
2	INSPECT SAS CONTROL MODULE SIGNAL (CAN2 LINE) FOR OPEN CIRCUIT <ul style="list-style-type: none"> Disconnect the DSC HU/CM connector. Disconnect the SAS control module connectors. Inspect for continuity between the following DSC HU/CM connector terminals (vehicle harness-side) and SAS control module connector terminals (vehicle harness-side): <ul style="list-style-type: none"> DSC HU/CM terminal S—SAS control module terminal 3H DSC HU/CM terminal P—SAS control module terminal 3I Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness, then go to Step 4.
3	INSPECT SAS CONTROL MODULE SIGNAL (CAN2 LINE) FOR SHORT CIRCUIT <ul style="list-style-type: none"> Inspect for continuity between the following DSC HU/CM connector terminals (vehicle harness-side) and body ground: <ul style="list-style-type: none"> DSC HU/CM terminal S—body ground DSC HU/CM terminal P—body ground Is there continuity? 	Yes	Repair or replace the wiring harness, then go to the next step.
		No	Go to the next step.
4	VERIFY THAT THE SAME DTC IS NOT PRESENT <ul style="list-style-type: none"> Reconnect all disconnected connectors. Clear the DTCs from the memory. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].) Start the engine and drive the vehicle at 10 km/h {6.2 mph} or more. Are the same DTCs present? 	Yes	Repeat the inspection from Step 1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION.)
		No	Go to the next step.
5	VERIFY THAT NO OTHER DTCS ARE PRESENT <ul style="list-style-type: none"> Are any other DTCs output? 	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSIS [DYNAMIC STABILITY CONTROL (DSC)].)
		No	DTC troubleshooting completed.