


DTC U0298:00 [SKYACTIV-G 2.0]

id0102h1910500

DTC U0298:00	CAN/LIN communication system: DC-DC converter information communication error with front body control module (FBCM)
DETECTION CONDITION	<ul style="list-style-type: none">• PCM detects a DC-DC converter information communication error from front body control module (FBCM). Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (other).• The check engine light does not illuminate.• FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.• The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none">• Communication line between DC-DC converter and front body control module (FBCM) malfunction• Communication line between front body control module (FBCM) and PCM malfunction• DC-DC converter connector or terminals malfunction• Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none">— Short to ground in wiring harness between DCDC 50 A fuse and DC-DC converter terminal L— DCDC 50 A fuse malfunction— Open circuit in wiring harness between battery positive terminal and DC-DC converter terminal L• Short to ground or open circuit in DC-DC converter power supply circuit<ul style="list-style-type: none">— Short to ground in wiring harness between C/U IG1 15 A fuse and DC-DC converter terminal H— C/U IG1 15 A fuse malfunction— Open circuit in wiring harness between IG1 relay terminal C and DC-DC converter terminal H• Front body control module (FBCM) connector or terminals malfunction• Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none">— DC-DC converter terminal C—Front body control module (FBCM) terminal 2H— Front body control module (FBCM) terminal 2P—PCM terminal 2AK— Front body control module (FBCM) terminal 2N—PCM terminal 2AL• Open circuit in wiring harness between DC-DC converter terminal C and front body control module (FBCM) terminal 2H• PCM connector or terminals malfunction• Open circuit in wiring harness between the following terminals:<ul style="list-style-type: none">— Front body control module (FBCM) terminal 2P—PCM terminal 2AK— Front body control module (FBCM) terminal 2N—PCM terminal 2AL• DC-DC converter malfunction• Front body control module (FBCM) malfunction• PCM malfunction



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
2	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition to off, then to ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	Go to the next step.
3	INSPECT DC-DC CONVERTER CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the DC-DC converter connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.

STEP	INSPECTION		ACTION
4	INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter connector is disconnected. • Measure the voltage at the DC-DC converter terminal L (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the DCDC 50 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 14.
5	INSPECT DC-DC CONVERTER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter connector is disconnected. • Switch the ignition ON (engine off or on). • Measure the voltage at the DC-DC converter terminal H (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the C/U IG1 15 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 14.
6	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the front body control module (FBCM) connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
7	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected. • Inspect for continuity between DC-DC converter terminal C (wiring harness-side) and body ground. • Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 14.
		No	Go to the next step.
8	INSPECT FRONT BODY CONTROL MODULE (FBCM) CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Front body control module (FBCM) terminal 2P — Front body control module (FBCM) terminal 2N • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 14.
		No	Go to the next step.
9	INSPECT DC-DC CONVERTER SIGNAL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter and front body control module (FBCM) connectors are disconnected. • Inspect for continuity between DC-DC converter terminal C (wiring harness-side) and front body control module (FBCM) terminal 2H (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 14.

STEP	INSPECTION		ACTION
10	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
11	INSPECT FRONT BODY CONTROL MODULE (FBCM) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the DC-DC converter, front body control module (FBCM) and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Front body control module (FBCM) terminal 2P—PCM terminal 2AK — Front body control module (FBCM) terminal 2N—PCM terminal 2AL • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 14.
12	INSPECT DC-DC CONVERTER <ul style="list-style-type: none"> • Inspect the DC-DC converter. (See DC-DC CONVERTER INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Replace the DC-DC converter, then go to Step 14. (See DC-DC CONVERTER REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
13	INSPECT FRONT BODY CONTROL MODULE (FBCM) <ul style="list-style-type: none"> • Inspect the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) INSPECTION.) • Is there any malfunction? 	Yes	Replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.)
		No	Go to the next step.
14	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
15	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.