

DTC P167B:00 [SKYACTIV-D 2.2]

id0102s4150000

DTC P167B:00	Fuel injection amount learning not completed in fuel injection system
DETECTION CONDITION	<ul style="list-style-type: none">Fuel injector injection amount correction is not completed. Diagnostic support note <ul style="list-style-type: none">This is a continuous monitor (other).The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.FREEZE FRAME DATA (Mode 2)/Snapshot data is available.DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none">Fuel injector injection amount correction is not completed.PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none">Verify related Service Information availability.Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none">If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none">Switch the ignition off, then ON (engine off).Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
3	PERFORM FUEL INJECTOR INJECTION AMOUNT CORRECTION <ul style="list-style-type: none">Perform the FUEL INJECTOR INJECTION AMOUNT CORRECTION. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 2.2].)Start the engine.Verify the glow indicator light.Does the glow indicator light illuminate?	Yes	Re-perform the PCM fuel injection amount adjustment. (Perform the FUEL INJECTOR DATA RESET and FUEL INJECTOR CODE PROGRAM using the M-MDS.) (See FUEL INJECTOR DATA RESET [SKYACTIV-D 2.2].) (See FUEL INJECTOR CODE PROGRAM [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
4	VERIFY DTCs <ul style="list-style-type: none">Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)Is the same DTC present?	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none">If a malfunction occurs, change the learning method (use/ do not use M-MDS), and re-implement the FUEL INJECTOR INJECTION AMOUNT CORRECTION. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to Step 6.
5	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none">Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)Is the same DTC present?	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none">If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION
6	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) Are any DTCs present? 	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No DTC troubleshooting completed.