

GEAR POSITION INDICATOR DOES NOT ILLUMINATE IN M POSITION [FW6A-EL, FW6AX-EL]

id050317103400

TROUBLESHOOTING ITEM	Gear position indicator does not illuminate in M position
DESCRIPTION	<ul style="list-style-type: none">• Gear position indicator in instrument cluster does not illuminate in M position with the ignition switched ON (engine off or on).
POSSIBLE CAUSE	<ol style="list-style-type: none">1. Instrument cluster malfunction <p>Note</p> <ul style="list-style-type: none">• When the ATF temperature is 132 °C {270 °F} or more, gear fixing is inhibited, the gear position indicator is turned off, and the control is changed to the automatic shift control.

Diagnostic procedure

STEP		INSPECTION		ACTION	
1	INSPECT INSTRUMENT CLUSTER FOR MALFUNCTION • Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) • Is there any malfunction?	Yes	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)		
		No	Symptom troubleshooting is completed.		