


## DC-DC CONVERTER CONTROL [SKYACTIV-D 2.2]

id0140z7004300

### Outline

- Stability of the power supply to the cabin has been realized by preventing decreases in the power supply due to battery voltage decreases while the engine is restarted by the i-stop control.
- When the engine is restarted by the i-stop control, the PCM sends a battery voltage (DC-DC converter downstream voltage) boost request signal to the DC-DC converter.

### Block Diagram



ac5wzn00002154

### Operation

- When the engine is restarted by the i-stop control, the PCM sends a voltage boost request signal to the DC-DC converter so that the DC-DC converter downstream voltage is maintained at 11.5—12.5 V.

