

DTC P06DA:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4009300

DTC P06DA:00	Engine oil solenoid valve circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"> The engine oil solenoid valve control current exceeds the specification or the control voltage at the PCM terminal 1AS is less than the specification relative to the PCM control condition. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits the engine oil control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Engine oil solenoid valve connector or terminals malfunction Short to ground or open circuit in engine oil solenoid valve power supply circuit <ul style="list-style-type: none"> Short to ground in wiring harness between ENGINE2 15 A fuse and engine oil solenoid valve terminal A ENGINE2 15 A fuse malfunction Open circuit in wiring harness between main relay terminal C and engine oil solenoid valve terminal A Short to ground in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1AS PCM connector or terminals malfunction Short to power supply in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1AS Open circuit in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1AS Engine oil solenoid valve malfunction PCM malfunction

MAIN RELAY TERMINAL C

ENGINE OIL SOLENOID VALVE

ENGINE OIL SOLENOID VALVE WIRING HARNESS-SIDE CONNECTOR

PCM

PCM WIRING HARNESS-SIDE CONNECTOR

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes No	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. Go to the next step.

STEP	INSPECTION		ACTION
2	INSPECT ENGINE OIL SOLENOID VALVE CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the engine oil solenoid valve connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
3	INSPECT ENGINE OIL SOLENOID VALVE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve connector is disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the engine oil solenoid valve terminal A (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE2 15 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible short to ground. — Replace the fuse. • If the fuse is deteriorated: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Repair or replace the wiring harness for a possible open circuit. Go to Step 9.
4	INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve connector is disconnected. • Switch the ignition off. • Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and body ground. • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to Step 9.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve and PCM connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the engine oil solenoid valve terminal B (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 9.
7	INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and PCM terminal 1AS (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT ENGINE OIL SOLENOID VALVE <ul style="list-style-type: none"> • Inspect the engine oil solenoid valve. (See ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is there any malfunction? 	Yes	Replace the engine oil solenoid valve, then go to the next step. (See ENGINE OIL SOLENOID VALVE REMOVAL/ INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.