

DTC P0882:00 [GW6A-EL, GW6AX-EL]

id050230823100

DTC P0882:00	TCM power supply voltage low
DETECTION CONDITION	<ul style="list-style-type: none"> Under the following conditions, the TCM power supply voltage is 8—10.5 V or less (varies with ATF temperature): <ul style="list-style-type: none"> 5 s or more has elapsed or battery voltage exceeds 11 V or more for 0.2 s since engine speed increases ~200 rpm or more of target idle speed. Selector lever position is D or R position. Diagnostic support note <ul style="list-style-type: none"> The check engine light illuminates if the TCM detects the above malfunction condition during the first drive cycle. The automatic transaxle warning light does not illuminate. PENDING CODE is available. FREEZE FRAME DATA is available. DTC is stored in the TCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Set to emergency mode. Inhibits learning control. Inhibits manual mode. Inhibits neutral idle control. Inhibits i-stop control. Inhibits AAS.
POSSIBLE CAUSE	<ul style="list-style-type: none"> PCM DTC is stored. Battery malfunction Generator malfunction TCM connector or terminals malfunction TCM power supply circuit malfunction <ul style="list-style-type: none"> Short to ground in wiring harness between AT 15 A fuse and TCM terminal A AT 15 A fuse malfunction Open circuit in wiring harness between battery positive terminal and TCM terminal A
SYSTEM WIRING DIAGRAM	

Diagnostic procedure

Diagnostic procedure		
STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA/SHOT DATA HAS BEEN RECORDED • Has the freeze frame data/snapshot data been recorded on the repair order?	Yes Go to the next step.
		No Record the freeze frame data/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	VERIFY PCM DTC <ul style="list-style-type: none"> Perform the PCM DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	INSPECT BATTERY <ul style="list-style-type: none"> Inspect the battery. (See BATTERY INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Recharge or replace the battery, then go to Step 8. (See BATTERY RECHARGING [SKYACTIV-D 2.2].) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
5	INSPECT GENERATOR <ul style="list-style-type: none"> Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the generator, then go to Step 8. (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
6	INSPECT TCM CONNECTOR AND TERMINALS <ul style="list-style-type: none"> Switch the ignition off. Disconnect the TCM connector. Visually inspect the TCM connector and terminals. Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
7	INSPECT TCM POWER SUPPLY CIRCUIT <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Access the PID VPWR using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM PID/ DATA MONITOR INSPECTION [GW6A-EL, GW6AX-EL].) Is the PID value B+? 	Yes	Go to the next step.
		No	Inspect the AT 15 A fuse. <ul style="list-style-type: none"> If the fuse is burnt out: <ul style="list-style-type: none"> Refer to the wiring diagram and verify whether or not there is a common connector between AT 15 A fuse and TCM terminal A. If there is a common connector: <ul style="list-style-type: none"> Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> Repair or replace the wiring harness which has a short to ground. Replace the fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the malfunctioning fuse. If the fuse is normal: <ul style="list-style-type: none"> Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and TCM terminal A. If there is a common connector: <ul style="list-style-type: none"> Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> Repair or replace the wiring harness which has an open circuit. Go to the next step.

STEP	INSPECTION	ACTION	
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [GW6A-EL, GW6AX-EL].) • Perform the following procedure to ensure that the DTC has been resolved: <ol style="list-style-type: none"> 1. Drive the vehicle for 5 s or more under the following condition: <ul style="list-style-type: none"> • Selector lever position: D or R position • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [GW6A-EL, GW6AX-EL].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [GW6A-EL, GW6AX-EL].)
		No	DTC troubleshooting completed.