
CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)]

id0902p2006200

CMDTC Memory Clearing Procedure

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
 - (1) Select "Self Test".
 - (2) Select "All CMDTCs".
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition to off.
6. Switch the ignition ON (engine off or on) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)
8. Verify that no DTCs are displayed.

ODDTC Memory Clearing Procedure

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
 - (1) Select "Self Test".
 - (2) Select "Modules".
 - (3) Select "F_BCM".
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition to off.
6. Switch the ignition ON (engine off or on) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].)
8. Verify that no DTCs are displayed.