

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	INSPECT THROTTLE BODY CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the throttle body connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
5	INSPECT THROTTLE VALVE ACTUATOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the throttle body and PCM connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> Throttle body terminal E—PCM terminal 1CG Throttle body terminal F—PCM terminal 1CC Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 8.
6	INSPECT THROTTLE VALVE <ul style="list-style-type: none"> Inspect the throttle valve. (See THROTTLE BODY INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the throttle body, then go to Step 8. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
7	INSPECT THROTTLE VALVE ACTUATOR <ul style="list-style-type: none"> Inspect the throttle valve actuator. (See THROTTLE BODY INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the throttle body, then go to the next step. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) Is the same DTC present? 	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.