


DTC P2101:00 [SKYACTIV-G 2.0]

id0102h1707700

DTC P2101:00	Throttle valve actuator control motor circuit range/performance problem
DETECTION CONDITION	<ul style="list-style-type: none"> • The PCM turns the main relay on, but if the input voltage is 6.0 V or less, then the PCM determines that the main relay control circuit voltage is low. • There is a system error in the electrical throttle control system of the PCM. <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA (Mode 2)/Snapshot data is available. • The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • Restricts the upper limit of the engine speed. • Stops the drive-by-wire control (throttle valve is open at approx. 8 ° by return spring force).
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Main relay malfunction • Short to ground or open circuit in main relay power supply circuit: <ul style="list-style-type: none"> — Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> • MAIN 200 A fuse—Main relay terminal D • MAIN 200 A fuse—Main relay terminal A — MAIN 200 A fuse and/or ENG.MAIN 40 A fuse malfunction — Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> • Battery positive terminal—Main relay terminal D • Battery positive terminal—Main relay terminal A • ENGINE2 15 A fuse malfunction • Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> — Main relay terminal C—PCM terminal 1CK — Main relay terminal C—PCM terminal 2S — Main relay terminal E—PCM terminal 2K • PCM connector or terminals malfunction • Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> — Main relay terminal C—PCM terminal 1CK — Main relay terminal C—PCM terminal 2S — Main relay terminal E—PCM terminal 2K • TP sensor No.1 and/or related circuit malfunction • TP sensor No.1 malfunction • TP sensor No.2 and/or related circuit malfunction • TP sensor No.2 malfunction • PCM malfunction



Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED • Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	Yes Go to the next step.
		No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY • Verify related Service Information availability. • Is any related Service Information available?	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.

STEP	INSPECTION	ACTION	
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition to off, then to ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	Go to the next step.
4	INSPECT MAIN RELAY <ul style="list-style-type: none"> Switch the ignition to off. Remove the main relay. Inspect the main relay. (See RELAY INSPECTION.) Is there any malfunction? 	Yes	Replace the main relay, then go to Step 12.
		No	Go to the next step.
5	INSPECT MAIN RELAY POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> Main relay is removed. Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> Main relay terminal D Main relay terminal A Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the MAIN 200 A fuse and ENG.MAIN 40 A fuse. <ul style="list-style-type: none"> If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the malfunctioning fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the malfunctioning fuse. If all fuses are normal: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible open circuit. Go to Step 12.
6	INSPECT ENGINE2 15 A FUSE <ul style="list-style-type: none"> Remove the ENGINE2 15 A fuse. Inspect the ENGINE2 15 A fuse. Is there any malfunction? 	Yes	If the fuse is blown: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. Replace the fuse. If the fuse is deteriorated: <ul style="list-style-type: none"> Replace the fuse. Go to Step 12.
		No	Reinstall the ENGINE2 15 A fuse, then go to the next step.
7	INSPECT MAIN RELAY CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Main relay is removed. Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> Main relay terminal C Main relay terminal E Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 12.
		No	Go to the next step.
8	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
9	INSPECT MAIN RELAY CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Main relay is removed. Verify that the PCM connector is disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> Main relay terminal C—PCM terminal 1CK Main relay terminal C—PCM terminal 2S Main relay terminal E—PCM terminal 2K Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 12.

STEP	INSPECTION		ACTION
10	INSPECT TP SENSOR NO.1 <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Inspect the TP sensor No.1. (See THROTTLE POSITION (TP) SENSOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Inspect the TP sensor No.1 related circuits and connectors. <ul style="list-style-type: none"> • If there is any malfunction: <ul style="list-style-type: none"> — Repair or replace the malfunctioning part according to the inspection results. • If there is no malfunction: <ul style="list-style-type: none"> — Replace the throttle body. (See INTAKE-AIR SYSTEM REMOVAL/ INSTALLATION [SKYACTIV-G 2.0].) Go to Step 12.
		No	Go to the next step.
11	INSPECT TP SENSOR NO.2 <ul style="list-style-type: none"> • Inspect the TP sensor No.2. (See THROTTLE POSITION (TP) SENSOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Inspect the TP sensor No.2 related circuits and connectors. <ul style="list-style-type: none"> • If there is any malfunction: <ul style="list-style-type: none"> — Repair or replace the malfunctioning part according to the inspection results. • If there is no malfunction: <ul style="list-style-type: none"> — Replace the throttle body. (See INTAKE-AIR SYSTEM REMOVAL/ INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
12	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the KOEO self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
13	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.