
GLOW PLUG INSPECTION [SKYACTIV-D 2.2]

id0113z7804300

1. Remove the glow plug short-cord. (See GLOW PLUG REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
2. Measure the resistance between the glow plug terminal and the body ground.

Glow plug resistance (specification)

Approx. 1.0 ohms [20 °C {68 °F}]

- If not within the specification, replace the glow plug. (See GLOW PLUG REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)