
GLOW PLUG CONTROL MODULE INSPECTION [SKYACTIV-D 2.2]

id0113z7705500

1. Perform the KOEO self-test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].)
2. Verify that a glow control module related DTC is detected.
 - If DTCs are detected, repair the malfunctioning part according to the applicable DTC troubleshooting.
 - If a DTC is not detected, go to the next step.
3. Inspect the following items:
 - Glow control module damage
 - Glow control module connector damage or corrosion
 - If there is any malfunction, repair or replace the malfunctioning part.
 - If there is no malfunction, replace the glow control module. (See GLOW PLUG CONTROL MODULE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)