

**DTC U0401:68 [BLIND SPOT MONITORING (BSM)]**

id0902i3952000

<b>System malfunction location</b>	<b>Error signal received from PCM</b>
<b>Detection condition</b>	<ul style="list-style-type: none"><li>• The BSM control module received an error signal from the PCM.</li></ul>
<b>Fail-safe</b>	<ul style="list-style-type: none"><li>• BSM is stopped.</li></ul>
<b>Possible cause</b>	<ul style="list-style-type: none"><li>• DTCs are stored in the PCM.</li><li>• PCM malfunction</li><li>• BSM control module malfunction</li></ul>
<b>System wiring diagram</b>	—

**Diagnostic Procedure**

<b>Step</b>	<b>Inspection</b>	<b>Action</b>
1	<b>VERIFY PCM DTCs</b> <ul style="list-style-type: none"><li>• Perform the DTC inspection for the PCM using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].)</li><li>• Is the DTC displayed?</li></ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See DTC TABLE [SKYACTIV-D 2.2].)
		No Go to the next step.
2	<b>PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS PCM</b> <ul style="list-style-type: none"><li>• Clear BSM control module DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].)</li><li>• Perform the DTC inspection for the BSM control module using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].)</li><li>• Is DTC U0401:68 displayed?</li></ul>	Yes Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No Go to Step 4.
3	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"><li>• Clear BSM control module DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].)</li><li>• Perform the DTC inspection for the BSM control module using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].)</li><li>• Is DTC U0401:68 displayed?</li></ul>	Yes Repeat the inspection from Step 1. <ul style="list-style-type: none"><li>• If the malfunction recurs, replace the BSM control module, then go to the next step. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)</li></ul>
		No Go to the next step.
4	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"><li>• Are any other DTCs displayed?</li></ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BLIND SPOT MONITORING (BSM)].)
		No DTC troubleshooting completed.