


TIE-ROD END INSPECTION

id061300802700

1. Inspect the tie-rod end for damage and the boot for cracks.
 - If there is any malfunction, replace the tie-rod end.
2. Inspect for excessive play.
 - If there is any malfunction, replace the tie-rod end.
3. Rotate the tie-rod end five times.
4. Install two nuts to the ball joint and measure the tie-rod end rotational torque using a torque wrench.
 - If not within the specification, replace the tie-rod end.

Tie-rod end rotational torque

0.5—2.1 N·m {5.1—21 kgf·cm, 4.5—18 in·lbf}



ac5wzw00001049