

DTC U3000:96 [START STOP UNIT]

id0902p6050000

System malfunction location	Start stop unit malfunction
Detection condition	• Start stop unit malfunction detected.
Fail-safe	• Cancel the i-stop control. (With i-stop)
Possible cause	• Start stop unit malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS START STOP UNIT <ul style="list-style-type: none">• Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].)• Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].)• Is DTC U3000:96 displayed?	Yes Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
2	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.