

FRONT SEAT BACK TRIM REMOVAL/INSTALLATION

id091300912000

Warning


- Handling a side air bag improperly can accidentally operate (deploy) the air bag, which may seriously injure you. Read the service warnings/cautions in the Workshop Manual before handling the front seat (side air bag integrated). (See AIR BAG SYSTEM SERVICE WARNINGS.) (See AIR BAG SYSTEM SERVICE CAUTIONS.)
- If the sliding mechanisms on both sides are not locked after assembling the front seat, the front seat will operate accidentally while the vehicle is driven, which could result in serious injury. After assembling the front seat, shake it up and down and verify that the sliding mechanism on the both sides are locked.

Caution

- If the slide lever is operated after the front seat is removed, the left/right slide positions will deviate and the adjuster unit could be damaged after the front seat is installed. After removing a front seat, do not operate the slide lever.
- Verify that there are no malfunctions in the forward/back slide of the seat and in the adjuster unit after installing a front seat.
- When performing the procedure with a front seat removed from the vehicle, perform the procedure on a clean cloth so as not to damage or soil the seat.


Driver-side (with power seat system)

1. Switch the ignition off (LOCK).
2. Disconnect the negative battery cable and wait for **1 min or more**. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
3. Remove the headrest.
4. Remove the front seat. (See FRONT SEAT REMOVAL/INSTALLATION.)
5. Remove fasteners A and set the front seat cushion trim aside.




ac5jjw00002776

6. Disconnect the side air bag module connector.




ac5wzw00003166

7. Disengage clip B.
8. Disconnect the front seat back warmer connector.
9. Disconnect the recliner motor/lumber support motor connectors.
10. Set hooks C aside in the direction of the arrow (1) shown in the figure.
11. Slide hook D in the order of arrows (2), (3), (4) shown in the figure and disconnect them from hook E.




ac5wzw00003167

12. Open fasteners F.
13. Partially peel back the seat back trim, release tabs G in the direction of the arrow (5) shown in the figure and pull out the pole guide in the direction of the arrow (6).




ac5wzw00003168

14. Partially peel back the front seat back trim and slide hook H in the order of the arrows (7), (8), and (9) shown in the figure, and remove it from the front seat back frame.




ac5wzw00003169

15. Pull out pin I in the direction of the arrow (10) shown in the figure, and using a flathead screwdriver wrapped in protective tape, release the tabs J in the direction of the arrow (11) shown in the figure while removing the clip K in the direction of the arrow (12).




ac5wzw00003170

16. Remove the side air bag module securing belt from the front seat back frame.




ac5uuw00002092

17. Pull the side air bag module wiring harness in the direction of the arrow (13) shown in the figure, and pull it out through the hole in the front seat back pad.
18. Pull the recliner motor wiring harness and lumbar support wiring harness in the direction of the arrow (14) shown in the figure, and pull it out through the hole in the front seat back pad.




ac5wzw00003105

19. Pull out the front seat back pad and front seat back trim, and the front seat back warmer connector towards the front of the front seat.



ac5jjw00002824

20. Lift up the front seat back trim and front seat back pad in the direction of the arrow (15) as a single unit and remove it from the front seat back frame.




ac5wzw00003106

21. Remove the C rings in the order of (16), (17), (18), (19), (20), and (21), shown in the figure, then remove the front seat back trim from the front seat back frame.

Caution

- If a damaged C rings are reused, it may not be possible to install the front seat back trim and front seat back pad correctly. When removing and installing C rings, be careful not to damage them.
- If the C rings are damaged, replace it with a new one.

22. Install in the reverse order of removal.




ac5wzw00003107

Driver-side (without power seat system)

Note


- There are two types of passenger-side front seats, A and B types. The location and the number of C-rings installed to the front seat back trim and front seat back pad differ depending on the type.

1. Switch the ignition off (LOCK).
2. Disconnect the negative battery cable and wait for **1 min or more**. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
3. Remove the headrest.
4. Remove the front seat. (See FRONT SEAT REMOVAL/INSTALLATION.)
5. Slide hook A in the order of arrows (1), (2), (3) shown in the figure and set the front seat cushion trim aside.




ac5uuw00001914

6. Disconnect the side air bag module connector.




ac5wzw00003171

7. Disconnect the front seat back warmer connector. (with seat warmer system)
8. Disengage clip B.
9. Set hook C aside in the direction of the arrow (4) shown in the figure.
10. Slide hook D in the order of arrows (5), (6), (7) shown in the figure and disconnect them from hook E.




ac5uuw00002095

11. Open fasteners F.
12. Partially peel back the seat back trim, release tabs G in the direction of the arrow (8) shown in the figure and pull out the pole guide in the direction of the arrow (9).




ac5uuw00002096

13. Partially peel back the front seat back trim and slide hook H in the order of the arrows (10), (11), and (12) shown in the figure, and remove it from the front seat back frame.




ac5uuw00002097

14. Pull out pin I in the direction of the arrow (13) shown in the figure, and using a flathead screwdriver wrapped in protective tape, release the tabs J in the direction of the arrow (14) shown in the figure while removing the clip K in the direction of the arrow (15).




ac5wzw00003784

15. Remove the side air bag module securing belt from the front seat back frame.




ac5uww00002092

16. Pull the side air bag module wiring harness in the direction of the arrow (16) shown in the figure, and pull it out through the hole in the front seat back pad.




ac5wzw00003109

17. Pull out the front seat back pad and front seat back trim, and the front seat back warmer connector (with seat warmer system) towards the front of the front seat.



ac5wzw00003172

18. Lift up the front seat back trim and front seat back pad in the direction of the arrow (17) as a single unit and remove it from the front seat back frame.




ac5wzw00003110

19. Remove the C rings in the order of (18), (19), (20), and (21) shown in the figure, and remove the front seat back trim from the front seat back pad. (type A)

Caution

- If a damaged C rings are reused, it may not be possible to install the front seat back trim and front seat back pad correctly. When removing and installing C rings, be careful not to damage them.
- If a C ring are damaged, replace it with a new one.




ac5uuw00002101

20. Remove the C rings in the order of (22), (23), (24), (25), (26), and (27), shown in the figure, then remove the front seat back trim from the front seat back pad. (type B)

Caution

- If a damaged C rings are reused, it may not be possible to install the front seat back trim and front seat back pad correctly. When removing and installing C rings, be careful not to damage them.
- If the C rings are damaged, replace it with a new one.



ac5wzw00003186

21. Install in the reverse order of removal.


Passenger-side

Note

- There are two types of passenger-side front seats, A and B types. The location and the number of C-rings installed to the front seat back trim and front seat back pad differ depending on the type.


1. Switch the ignition off (LOCK).
2. Disconnect the negative battery cable and wait for **1 min or more**. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
3. Remove the headrest.
4. Remove the front seat. (See FRONT SEAT REMOVAL/INSTALLATION.)

5. Slide hook A in the order of arrows (1), (2), (3) shown in the figure and set the front seat cushion trim aside.



ac5wzw00003173


6. Disconnect the side air bag module connector.



ac5wzw00003174


7. Disconnect the front seat back warmer connector. (with seat warmer system)
8. Disengage clip B.
9. Set hook C aside in the direction of the arrow (4) shown in the figure.

10. Slide hook D in the order of arrows (5), (6), (7) shown in the figure and disconnect them from hook E.




ac5uuw00002102

11. Open fasteners F.
12. Partially peel back the seat back trim, release tabs G in the direction of the arrow (8) shown in the figure and pull out the pole guide in the direction of the arrow (9).




ac5uuw00002103

13. Partially peel back the front seat back trim and slide hook H in the order of the arrows (10), (11), and (12) shown in the figure, and remove it from the front seat back frame.




ac5uuw00001920

14. Pull out pin I in the direction of the arrow (13) shown in the figure, and using a flathead screwdriver wrapped in protective tape, release the tabs J in the direction of the arrow (14) shown in the figure while removing the clip K in the direction of the arrow (15).




ac5uuw00001921

15. Remove the side air bag module securing belt from the front seat back frame.




ac5uuw00001922

16. Pull the side air bag module wiring harness in the direction of the arrow (16) shown in the figure, and pull it out through the hole in the front seat back pad.




ac5wzw00003111

17. Pull out the front seat back pad and front seat back trim, and the front seat back warmer connector (with seat warmer system) towards the front of the front seat.



ac5wzw00003175

18. Lift up the front seat back trim and front seat back pad in the direction of the arrow (17) as a single unit and remove it from the front seat back frame.




ac5wzw00003110

19. Remove the C rings in the order of (18), (19), (20), (21), (22), and (23) shown in the figure, then remove the front seat back trim from the front seat back pad. (type A)

Caution

- If a damaged C rings are reused, it may not be possible to install the front seat back trim and front seat back pad correctly. When removing and installing C rings, be careful not to damage them.
- If the C rings are damaged, replace it with a new one.




ac5wzw00003176

20. Remove the C rings in the order of (24), (25), (26), and (27) shown in the figure, then remove the front seat back trim from the front seat back pad. (type B)

Caution

- If a damaged C rings are reused, it may not be possible to install the front seat back trim and front seat back pad correctly. When removing and installing C rings, be careful not to damage them.
- If the C rings are damaged, replace it with a new one.

21. Install in the reverse order of removal.



ac5wzw00003113