


DTC P0643:00 [SKYACTIV-D 2.2]

id0102s4315600


DTC P0643:00	Constant voltage power supply circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> When the following condition is met, the output voltage of the 5 V power supply terminal exceeds 4.1 V for a continuous 1 s: MONITORING CONDITIONS <ul style="list-style-type: none"> Battery voltage: 8—20 V Diagnostic support note This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits the EGR control. Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> APP sensor connector or terminals malfunction CKP sensor connector or terminals malfunction MAP sensor No.2 connector or terminals malfunction Engine oil temperature sensor/engine oil pressure sensor connector or terminals malfunction MAF sensor/IAT sensor No.1 connector or terminals malfunction Regulating valve position sensor connector or terminals malfunction Power brake unit vacuum sensor connector or terminals malfunction Refrigerant pressure sensor connector or terminals malfunction PCM connector or terminals malfunction Short to power supply in wiring harness between the following terminals: <ul style="list-style-type: none"> APP sensor terminal A—PCM terminal 2AM CKP sensor terminal A—PCM terminal 1J MAP sensor No.2 terminal C—PCM terminal 1CN Engine oil temperature sensor/engine oil pressure sensor terminal A—PCM terminal 1DN MAF sensor/IAT sensor No.1 terminal D—PCM terminal 2AC Regulating valve position sensor terminal C—PCM terminal 1BO Power brake unit vacuum sensor terminal C—PCM terminal 2BB Refrigerant pressure sensor terminal A—PCM terminal 2BB PCM malfunction

DTC
P0643:00

Constant voltage power supply circuit high input




APP SENSOR
WIRING HARNESS-SIDE
CONNECTOR




CKP SENSOR
WIRING HARNESS-SIDE
CONNECTOR




MAP SENSOR NO.2
WIRING HARNESS-SIDE
CONNECTOR




REGULATING VALVE
POSITION SENSOR
WIRING HARNESS-SIDE
CONNECTOR




POWER BRAKE UNIT
VACUUM SENSOR
WIRING HARNESS-SIDE
CONNECTOR




MAF SENSOR/
IAT SENSOR NO.1
WIRING HARNESS-SIDE
CONNECTOR






REFRIGERANT
PRESSURE SENSOR
WIRING HARNESS-SIDE
CONNECTOR



ENGINE OIL TEMPERATURE SENSOR/
ENGINE OIL PRESSURE SENSOR
WIRING HARNESS-SIDE
CONNECTOR



PCM
WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	INSPECT APP SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the APP sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
5	INSPECT CKP SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the CKP sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
6	INSPECT MAP SENSOR NO.2 CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the MAP sensor No.2 connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
7	INSPECT ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the engine oil temperature sensor/ engine oil pressure sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
8	INSPECT MAF SENSOR/IAT SENSOR NO.1 CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the MAF sensor/IAT sensor No.1 connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
9	INSPECT REGULATING VALVE POSITION SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the regulating valve position sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.

STEP	INSPECTION		ACTION
10	INSPECT POWER BRAKE UNIT VACUUM SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the power brake unit vacuum sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
11	INSPECT REFRIGERANT PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the refrigerant pressure sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
12	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
13	INSPECT EACH POWER SUPPLY CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the APP sensor and CKP sensor and MAP sensor No.2 and engine oil temperature sensor/engine oil pressure sensor and MAF sensor/IAT sensor No.1 and regulating valve position sensor and power brake unit vacuum sensor and refrigerant pressure sensor connectors are disconnected. • Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> — APP sensor terminal A — CKP sensor terminal A — MAP sensor No.2 terminal C — Engine oil temperature sensor/engine oil pressure sensor terminal A — MAF sensor/IAT sensor No.1 terminal D — Regulating valve position sensor terminal C — Power brake unit vacuum sensor terminal C — Refrigerant pressure sensor terminal A • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
14	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
15	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.