

DTC U0320:00	EPS control module error
DETECTION CONDITION	<ul style="list-style-type: none"> When any of the following conditions is met: <ul style="list-style-type: none"> CAN communication line malfunction between PCM and EPS control module EPS control module internal malfunction Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none"> CAN drive error (instrument cluster or PCM) CAN communication line malfunction between PCM and EPS control module <ul style="list-style-type: none"> EPS control module terminal 2A—Front body control module (FBCM) terminal 2K EPS control module terminal 2D—Front body control module (FBCM) terminal 2I Front body control module (FBCM) terminal 2P—PCM terminal 2AK Front body control module (FBCM) terminal 2N—PCM terminal 2AL Front body control module (FBCM) malfunction EPS control module connector or terminals malfunction PCM connector or terminals malfunction EPS control module malfunction PCM malfunction

The diagram illustrates the CAN communication network. The EPS Control Module is connected to the FBCM via terminals 2A/2D and 2K/2I. The FBCM is then connected to the PCM via terminals 2P/2N and 2AK/2AL. Below the main diagram, three connector layouts are shown: the EPS Control Module Wiring Harness-Side Connector (terminals 2H, 2G, 2F, 2E, 2D, 2C, 2B, 2A), the FBCM Wiring Harness-Side Connector (terminals 2AA through 2B), and the PCM Wiring Harness-Side Connector (terminals 2BE through 2AO and 2AE through 2D).

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	VERIFY DTC FOR MODULE COMMUNICATION <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
3	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTC <ul style="list-style-type: none"> Perform the front body control module (FBCM) DTC inspection using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	Go to the next step.
4	VERIFY EPS CONTROL MODULE DTC <ul style="list-style-type: none"> Perform the EPS control module DTC inspection using the M-MDS. (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.)
		No	Go to the next step.
5	VERIFY INSTRUMENT CLUSTER DTC <ul style="list-style-type: none"> Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No	Go to the next step.
6	INSPECT EPS CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the EPS control module connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
7	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	CAN communication line can be considered the cause. <ul style="list-style-type: none"> Repair or replace the following wiring harnesses. <ul style="list-style-type: none"> EPS control module terminal 2A—Front body control module (FBCM) terminal 2K EPS control module terminal 2D—Front body control module (FBCM) terminal 2I Front body control module (FBCM) terminal 2P—PCM terminal 2AK Front body control module (FBCM) terminal 2N—PCM terminal 2AL If the malfunction recurs, replace the EPS control module. (See STEERING WHEEL AND COLUMN REMOVAL/INSTALLATION.) Go to the next step.

STEP	INSPECTION	ACTION	
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.