

**DTC P182F:00**

id030200200200

<b>DTC P182F:00</b>	<b>Excessive load detected on 4WD part</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"><li>• 4WD CM detects excessive load</li></ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"><li>• 4WD protection condition (4WD control paused)</li><li>• 4WD warning light: Flashed</li></ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"><li>• Detects excessive load on 4WD part to switch to 2WD and protect the system</li></ul>

**Diagnostic procedure**

Diagnostic procedure			
STEP	INSPECTION	ACTION	
1	SWITCH THE IGNITION TO OFF AND ALLOW 4WD CM TO COOL DOWN.		
2	VERIFY THAT THE SAME DTC IS NOT PRESENT • Clear the DTCs from the memory. (See ELECTRONIC 4WD CONTROL SYSTEM ON-BOARD DIAGNOSIS.) • Is the same DTC present?	Yes	Repeat the inspection from Step 1.
		No	Go to the next step.
3	VERIFY THAT NO OTHER DTCS ARE PRESENT • Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See ELECTRONIC 4WD CONTROL SYSTEM ON-BOARD DIAGNOSIS.)
		No	DTC troubleshooting completed.