

CAR-NAVIGATION SYSTEM DOES NOT OPERATION [CAR-NAVIGATION SYSTEM]

id0903e8100100

Possible DTC	Even if the map screen is touched, the car-navigation system cannot be operated
POSSIBLE CAUSE	<ul style="list-style-type: none">• Audio unit malfunction (bad LCD panel)• Car-navigation unit malfunction

Diagnostic Procedure

Step	Inspection	Action	
1	DETERMINE IF MALFUNCTION CAUSE IS AUDIO UNIT LCD PANEL <ul style="list-style-type: none">• Switch the ignition ON and launch the audio unit diagnostic assist function. (See DIAGNOSTIC ASSIST FUNCTION [AUDIO].)• Select diagnostic assist code 01 display inspection.• Is the display normal?	Yes	Go to the next step.
		No	Replace the audio unit. (See AUDIO UNIT REMOVAL/INSTALLATION.)
2	DETERMINE IF MALFUNCTION CAUSE IS CAR-NAVIGATION UNIT <ul style="list-style-type: none">• Select diagnostic assist code 16 external device connection information clearing.• Switch the ignition off (LOCK).• Switch the ignition ON (engine off or on).• Launch the audio unit diagnostic assist function. (See DIAGNOSTIC ASSIST FUNCTION [AUDIO].)• Select diagnostic assist code 15 vehicle NAVI signal verification.• Is NAVI (USB) NG displayed?	Yes	Replace the car-navigation unit. (See CAR-NAVIGATION UNIT REMOVAL/INSTALLATION.)
		No	Replace the audio unit. (See AUDIO UNIT REMOVAL/INSTALLATION.)