


CLUTCH COMPONENT ASSEMBLY

id051700663700

Structural View



azzjw00001532


1	High clutch drum component
2	High clutch piston
3	Springs and retainer component (outer diameter approx. 79.5 mm {3.13 in})
4	Seal plate
5	Snap ring (outer diameter approx. 56.5 mm {2.22 in})
6	Driven plate (inner diameter approx. 95.5 mm {3.76 in})
7	Drive plate (outer diameter approx. 116.8 mm {4.598 in})
8	Retaining plate (inner diameter approx. 95.5 mm {3.76 in})

9	Snap ring (outer diameter approx. 127.4 mm {5.016 in}) (selection)
10	Wave spring
11	Driven plate (inner diameter approx. 139.9 mm {5.508 in})
12	Drive plate (outer diameter approx. 159.1 mm {6.264 in})
13	Retaining plate (inner diameter approx. 139.9 mm {5.508 in})
14	Snap ring (outer diameter approx. 169.3 mm {6.665 in}) (selection)


Assembly Procedure

- Assemble the high clutch piston using the following procedure:
 - Apply ATF (ATF FZ) to the high clutch piston lip.

(2) Assemble the high clutch piston.



azzjiw00000843




azzjiw00000844


2. Assemble the springs and retainer component.

Note

- Springs and retainer component size: Outer diameter approx. 79.5 mm {3.13 in}




azzjiw00001257




azzjiw00000846

3. Assemble the seal plate using the following procedure:
(1) Apply ATF (ATF FZ) to the seal plate lip.

(2) Assemble the seal plate.



azzjw00000847




azzjw00000848

4. Assemble the snap ring using the following procedure:


Note

- Snap ring size: Outer diameter approx. 56.5 mm {2.22 in}

(1) Set the snap ring to the top of the seal plate.



azzjw00000849



azzjw00000850

(2) Install the SSTs.

Note


- When installing the SST (49 G019 025) to the SST (49 G019 026), use the nuts included with the SST (49 G019 025), or M8×1.25 nuts.

A : Nut included with SST (49 G019 025), or M8×1.25 nut


B : Washer

A : Nut included with SST (49 G019 025), or M8×1.25 nut

B : Washer



azzjiw00000851




azzjiw00000852

(3) Tighten the SST (49 G019 029) until the snap ring groove of the high clutch drum component comes out.

Caution

- If the SST (49 G019 029) is tightened with excessive force, surrounding parts could be damaged. Stop tightening the SST when the snap ring groove of the high clutch drum component comes out.

A : Snap ring groove




azzjiw00000853

(4) Assemble the snap ring.


Caution

- After assembling the snap ring, verify that the snap ring is securely inserted into the bottom of the snap ring groove.




azzjiw00000854

A : Snap ring




azzjjw00000855

- (5) Loosen the SST (49 G019 029) and remove the SSTs.



azzjjw00000856

A : Nut included with SST (49 G019 025), or M8×1.25 nut
B : Washer



azzjjw00000857

5. Assemble the drive plates and driven plates using the following procedure:

Note

- Drive plate size: Outer diameter approx. 116.8 mm {4.598 in}
- Driven plate size: Inner diameter approx. 95.5 mm {3.76 in}

- (1) Apply ATF (ATF FZ) to the drive plates and driven plates.

Caution


- If the drive plate is replaced with a new one, immerse it in ATF (ATF FZ) for 2 hours or more to permeate the facing with ATF.

- (2) Assemble the drive plates and driven plates.


Assembly order

Driven plate—drive plate—driven plate—drive plate—driven plate—drive plate—driven plate—drive plate
—driven plate—drive plate

A : Drive plate
B : Driven plate



azzjiw00000858




azzjiw00000859


6. Assemble the retaining plate.

Note

- Retaining plate size: Inner diameter approx. 95.5 mm {3.76 in}



azzjiw00000860



azzjiw00000861

7. Assemble the snap ring using the following procedure:

Note

- Snap ring size: Outer diameter approx. 127.4 mm {5.016 in}

(1) Measure the high clutch clearance and select the appropriate snap ring. (See HIGH CLUTCH CLEARANCE MEASUREMENT/ADJUSTMENT.)

Note


- If the snap ring is assembled for the high clutch clearance measurement/adjustment, the following snap ring assembly procedure is not necessary.

(2) Assemble the selected snap ring in Step (1).


Caution

- After assembling the snap ring, verify that the snap ring is securely inserted into the bottom of the snap ring groove.

A : Selection




azzjjw00000862




azzjjw00000863

8. Assemble the wave spring.



azzjjw00000864



azzjjw00000865

9. Assemble the drive plates and driven plates using the following procedure:

Note

- Drive plate size: Outer diameter approx. 159.1 mm {6.264 in}

- Driven plate size: Inner diameter approx. 139.9 mm {5.508 in}

(1) Apply ATF (ATF FZ) to the drive plates and driven plates.

Caution

- If the drive plate is replaced with a new one, immerse it in ATF (ATF FZ) for 2 hours or more to permeate the facing with ATF.


(2) Assemble the drive plates and driven plates.

Assembly order


Driven plate—drive plate—driven plate—drive plate—driven plate—drive plate—driven plate—drive plate
—driven plate—drive plate

A : Drive plate

B : Driven plate



azzjiw00000866




azzjiw00000867


10. Assemble the retaining plate.

Note

- Retaining plate size: Inner diameter approx. 139.9 mm {5.508 in}



azzjiw00000868



azzjjw00000869

11. Assemble the snap ring using the following procedure:

Note

- Snap ring size: Outer diameter approx. 169.3 mm {6.665 in}

(1) Measure the low clutch clearance and select the appropriate snap ring. (See LOW CLUTCH CLEARANCE MEASUREMENT/ADJUSTMENT.)

Note

- If the snap ring is assembled for the low clutch clearance measurement/adjustment, the following snap ring assembly procedure is not necessary.

(2) Assemble the selected snap ring in Step (1) to the position shown in the figure.


Caution

- Assemble so that the end gap of the snap ring is positioned diagonally opposed to the end gap of the snap ring for the high clutch.
- After assembling the snap ring, verify that the snap ring is securely inserted into the bottom of the snap ring groove.


A : Selection

A : Snap ring (low clutch)

B : Snap ring (high clutch)



azzjjw00000870



azzjjw00000871


12. Perform a simple inspection of the low clutch and high clutch using the following procedure:

(1) Set the oil pump on the workbench as shown in the figure.

Note

- Using the rubber plates, adjust the alignment surface of the oil pump with the transaxle case so that it is level.

A : Rubber plate




azzjiw00000802


(2) Assemble the thrust needle bearing to the clutch component using the following procedure:

Note

- Thrust needle bearing size: Outer diameter approx. 72.7 mm {2.86 in}
- 1) To prevent the thrust needle bearing from dropping out, apply ATF (ATF FZ) to the thrust needle bearing.
 - 2) Assemble the thrust needle bearing.




azzjiw00000803




azzjiw00000804

(3) Assemble the parts assembled together in Step (2) to the oil pump.



azzjiw00000805



azzjw00000806

- (4) Blow compressed air into the oil passage shown in the figure and verify the operation condition of the low clutch.

Warning

- Always wear protective eye wear when using the air compressor. Otherwise, ATF or dirt particles blown off by the air compressor could get into the eyes.


Caution

- To prevent damage to parts, always use an air compressor which is adjusted to the indicated pressure.

Compressed air pressure

0.39—0.44 MPa {4.0—4.4 kgf/cm², 57—63 psi}

- If there is a malfunction, perform disassembly again, verify the cause and repair the applicable part. (See CLUTCH COMPONENT DISASSEMBLY.)



azzjw00000807

- (5) Blow compressed air into the oil passage shown in the figure and verify the operation condition of the high clutch.

Warning

- Always wear protective eye wear when using the air compressor. Otherwise, ATF or dirt particles blown off by the air compressor could get into the eyes.


Caution

- To prevent damage to parts, always use an air compressor which is adjusted to the indicated pressure.

Compressed air pressure


0.39—0.44 MPa {4.0—4.4 kgf/cm², 57—63 psi}

- If there is a malfunction, perform disassembly again, verify the cause and repair the applicable part. (See CLUTCH COMPONENT DISASSEMBLY.)




azzjw00000808

(6) Remove the clutch component.




azzjiw00000809

(7) Remove the thrust needle bearing.



azzjiw00000810

(8) Take the oil pump off the rubber plates.



azzjiw00001258