

# DTC B108C:24 [START STOP UNIT]

id0902p6019600

<b>System malfunction location</b>	<b>Push button start switch 2 circuit malfunction</b>
<b>Detection condition</b>	• The start stop unit detects that push button start switch 2 is kept in an off condition <b>5 times or more</b> even though push button start switch 1 is on.
<b>Fail-safe</b>	—
<b>Possible cause</b>	<ul style="list-style-type: none"> <li>• Push button start connector or terminal malfunction</li> <li>• Open circuit in wiring harness between push button start terminal E and body ground</li> <li>• Start stop unit connector or terminal malfunction</li> <li>• Open circuit in wiring harness between start stop unit terminal 2J and push button start terminal I</li> <li>• Push button start switch 2 malfunction</li> <li>• Start stop unit malfunction</li> </ul>
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>START STOP UNIT</p> </div> <div style="text-align: center;"> <p>PUSH BUTTON START</p> </div> </div>	

## Diagnostic Procedure

Step	Inspection	Action	
1	<b>INSPECT PUSH BUTTON START CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition to off.</li> <li>• Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Disconnect the push button start connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.

Step	Inspection	Action
2	<b>INSPECT PUSH BUTTON START SWITCH 2 CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the push button start connector is disconnected.</li> <li>• Inspect for continuity between push button start terminal E (vehicle wiring harness side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes Go to the next step.
		No Repair or replace the wiring harness which has an open circuit, then go to Step 6.
3	<b>INSPECT START STOP UNIT CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the start stop unit connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 6.
4	<b>INSPECT PUSH BUTTON START SWITCH 2 CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the push button start and start stop unit connectors are disconnected.</li> <li>• Inspect the wiring harness for continuity between start stop unit terminal 2J (vehicle wiring harness side) and push button start terminal I (vehicle wiring harness side).</li> <li>• Is there continuity?</li> </ul>	Yes Go to the next step.
		No Repair or replace the wiring harness which has an open circuit, then go to Step 6.
5	<b>INSPECT PUSH BUTTON START SWITCH 2</b> <ul style="list-style-type: none"> <li>• Inspect push button start switch 2. (See PUSH BUTTON START INSPECTION.)</li> <li>• Is push button start switch 2 normal?</li> </ul>	Yes Go to the next step.
		No Replace the push button start, then go to the next step. (See PUSH BUTTON START REMOVAL/INSTALLATION.)
6	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>• Reconnect all the disconnected connectors.</li> <li>• Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)</li> <li>• Clear DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].)</li> <li>• Switch the ignition ON (engine off or on) and press the push button start <b>5 times or more</b>.</li> <li>• Perform the DTC inspection for the start stop unit using the M-MDS. (See DTC INSPECTION [START STOP UNIT].)</li> <li>• Is DTC B108C:24 displayed?</li> </ul>	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
7	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>• Are any other DTCs displayed?</li> </ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].)
		No DTC troubleshooting completed.