

---

## EGR VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0140z7960300

### Note

- Because the EGR valve position sensor is integrated in the EGR valve, replacing the EGR valve position sensor includes replacement of the EGR valve.

1. Remove the EGR valve. (See EGR VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)