





DTC P0203:00	Fuel injector No.3 circuit operating abnormally
DETECTION CONDITION	<ul style="list-style-type: none"> The injection verification signal is not detected during the fuel injector No.3 operation when the following conditions are met: MONITORING CONDITIONS <ul style="list-style-type: none"> Battery voltage: 8 V or more Diagnostic support note This is an intermittent monitor (fuel system). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> PCM restricts engine torque. Inhibits the EGR control. Inhibits the diesel particulate filter regeneration control. Inhibits engine-stop by operating the i-stop function. PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Fuel injector No.3 connector or terminals malfunction PCM connector or terminals malfunction Open circuit in wiring harness between fuel injector No.3 terminal B and PCM terminal 1CS Fuel injector No.3 malfunction PCM malfunction



PCM WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes No	Go to the next step. Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Information availability. • Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	INSPECT FUEL INJECTOR NO.3 CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the fuel injector No.3 connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	INSPECT FUEL INJECTOR NO.3 CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the fuel injector No.3 and PCM connectors are disconnected. • Inspect for continuity between fuel injector No.3 terminal B (wiring harness-side) and PCM terminal 1CS (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 7.
6	INSPECT FUEL INJECTOR NO.3 <ul style="list-style-type: none"> • Inspect the fuel injector No.3. (See FUEL INJECTOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the fuel injector No.3, then go to the next step. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.