
NOISE OCCURS AT IDLE WHEN VEHICLE IS STOPPED IN D, M OR R POSITION [GW6A-EL, GW6AX-EL]

id050320102400

TROUBLESHOOTING ITEM	Noise occurs at idle when vehicle is stopped in D, M or R position
DESCRIPTION	• Transaxle is noisy in driving positions when vehicle is idling.
POSSIBLE CAUSE	1. Engine control system malfunction 2. Automatic transaxle internal parts malfunction — Torque converter internal parts malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY IF MALFUNCTION CAUSE IS ENGINE CONTROL SYSTEM OR TORQUE CONVERTER • Inspect the engine condition. • Is there any malfunction?	Yes Go to the appropriate symptom troubleshooting. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-D 2.2].)
		No Replace the automatic transaxle. (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [GW6A-EL].) (See AUTOMATIC TRANSAXLE REMOVAL/ INSTALLATION [GW6AX-EL].)