

DTC U2100:00 [INSTRUMENT CLUSTER]

id0902e8999600

System malfunction location	Instrument cluster configuration error
Detection condition	<ul style="list-style-type: none">• Instrument cluster configuration error detected as follows:<ul style="list-style-type: none">— No configuration of instrument cluster— Instrument cluster configuration has not been correctly performed.
Fail-safe	—
Possible cause	<ul style="list-style-type: none">• Instrument cluster configuration error• Instrument cluster malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA) <ul style="list-style-type: none">• Using the M-MDS, perform the instrument cluster configuration with the As-Built data. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)• Clear DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].)• Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].)• Is DTC U2100:00 displayed?	Yes Using the M-MDS, re-perform the instrument cluster configuration using the As-Built data, then go to the next step. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)
		No Go to Step 3.
2	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none">• Clear DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].)• Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].)• Is DTC U2100:00 displayed?	Yes Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No Go to the next step.
3	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].)
		No DTC troubleshooting completed.