


DTC P0628:00	Fuel pump control module circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> When the PCM outputs a duty signal to the fuel pump control module, the difference in voltage between fuel pump unit terminals B and D is less than 1.5 V for a continuous 5 s. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	—
POSSIBLE CAUSE	<ul style="list-style-type: none"> Fuel pump unit connector or terminals malfunction Fuel pump unit malfunction Fuel pump control module connector or terminals malfunction Short to ground in wiring harness between fuel pump unit terminal A and fuel pump control module terminal 2C Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Fuel pump unit terminal A—Fuel pump control module terminal 2C Fuel pump unit terminal B—Fuel pump control module terminal 2D Fuel pump control module malfunction PCM malfunction



Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes: Go to the next step. No: Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes: Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. No: Go to the next step.

STEP	INSPECTION		ACTION
3	INSPECT FUEL PUMP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the fuel pump unit connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT FUEL PUMP UNIT <ul style="list-style-type: none"> Inspect the fuel pump unit. (See FUEL PUMP UNIT INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the fuel pump unit, then go to Step 9. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
5	INSPECT FUEL PUMP CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the fuel pump control module connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	INSPECT FUEL PUMP UNIT CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the fuel pump unit and fuel pump control module connectors are disconnected. Inspect for continuity between fuel pump unit terminal A (wiring harness-side) and body ground. Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to ground, then go to Step 9.
		No	Go to the next step.
7	INSPECT FUEL PUMP UNIT CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the fuel pump unit and fuel pump control module connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> Fuel pump unit terminal A—Fuel pump control module terminal 2C Fuel pump unit terminal B—Fuel pump control module terminal 2D Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT FUEL PUMP CONTROL MODULE <ul style="list-style-type: none"> Inspect the fuel pump control module. (See FUEL PUMP CONTROL MODULE INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? 	Yes	Replace the fuel pump control module, then go to the next step. (See FUEL PUMP CONTROL MODULE REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Make sure to reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.