

CD PLAYER DOES NOT EJECT THE CD [CD PLAYER]

id0903k3016600

Possible DTC	CD player does not eject the CD	
	Using the M-MDS	B1D19:79
	Without using M-MDS (On-board diagnostic test mode)	10:Er01
Possible cause	<ul style="list-style-type: none"> Defective CD. (e.g., cracked, badly bent, rough edges, scratch, dirty CD, condensation) Non-conventional discs (e.g., 8 cm (3 in) disc adapter, heart-shaped disc, octagonal disc) Poor connection of audio unit connector or terminal (e.g., damaged, bent, pulled-out pin, corrosion) Deformed disc is used (e.g., out of specification (thickness), bent disc). Multiple CDs are inserted into the CD player at the same time Audio unit malfunction <p>Note</p> <ul style="list-style-type: none"> The CD may be malfunctioning if the CD player does not eject the certain CD only. Inspect the CD player operation using the CD known to be good. 	

Diagnostic procedure

STEP	INSPECTION	ACTION
1	<ul style="list-style-type: none"> Can the disc in which the malfunction occurs be specified? 	Yes
		No
2	<ul style="list-style-type: none"> Switch the ignition off (LOCK). Inspect the connection of the audio unit connector (24-pin). Inspect both audio unit connector and wiring harness-side connector for poor connection. (such as damaged/bent/pulled-out pins, corrosion) All the pins and connector normal? 	Yes
		No
3	<ul style="list-style-type: none"> Insert the CD into the CD player. Does the CD insert into the CD player smoothly? 	Yes
		No
4	<ul style="list-style-type: none"> Is the CD ejected from the CD player? 	Yes
		No