

DTC P0223:00 [SKYACTIV-D 2.2]

id0102s4702900

DTC P0223:00	APP sensor No.2 circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the input voltage from APP sensor No.2 when the engine is running. If the input voltage at the PCM terminal 2AS is more than 4.7 V for 0.5 s, the PCM determines that the APP sensor No.2 circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> PCM restricts engine torque. Inhibits the EGR control. Inhibits the diesel particulate filter regeneration control. Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> APP sensor connector or terminals malfunction PCM connector or terminals malfunction Short to power supply in wiring harness between APP sensor terminal E and PCM terminal 2AS APP sensor No.2 power supply circuit and signal circuit are shorted to each other Open circuit in wiring harness between APP sensor terminal D and PCM terminal 2AT APP sensor No.2 malfunction PCM malfunction
<div> <div> <p>⑧</p> <p>APP SENSOR NO.2 (APP SENSOR)</p> <p>APP SENSOR WIRING HARNESS-SIDE CONNECTOR</p> <p>PCM WIRING HARNESS-SIDE CONNECTOR</p> </div> </div>	

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes Go to the next step. No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. No Go to the next step.

STEP	INSPECTION		ACTION
3	INSPECT APP SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the APP sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	INSPECT APP SENSOR NO.2 CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the APP sensor and PCM connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the APP sensor terminal E (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 9.
6	INSPECT APP SENSOR NO.2 POWER SUPPLY CIRCUIT AND SIGNAL CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> Verify that the APP sensor and PCM connectors are disconnected. Switch the ignition off. Inspect for continuity between APP sensor terminals F and E (wiring harness-side). Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 9.
		No	Go to the next step.
7	INSPECT APP SENSOR NO.2 GROUND CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the APP sensor and PCM connectors are disconnected. Inspect for continuity between APP sensor terminal D (wiring harness-side) and PCM terminal 2AT (wiring harness-side). Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT APP SENSOR NO.2 <ul style="list-style-type: none"> Reconnect all disconnected connectors. Inspect the APP sensor No.2. (See ACCELERATOR PEDAL POSITION (APP) SENSOR INSPECTION [SKYACTIV-D 2.2].) <ul style="list-style-type: none"> Is there any malfunction? 	Yes	Replace the accelerator pedal, then go to the next step. (See ACCELERATOR PEDAL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) <ul style="list-style-type: none"> Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) <ul style="list-style-type: none"> Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) <ul style="list-style-type: none"> Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.