

---

## RVM WARNING INDICATOR LIGHT REMOVAL/INSTALLATION

id092200015300

### Note

- The RVM warning indicator lights are integrated into the outer mirror glass.
- For the RVM warning indicator light removal/installation, refer to the outer mirror glass removal/installation. (See OUTER MIRROR GLASS REMOVAL.) (See OUTER MIRROR GLASS INSTALLATION.)