

---

## CONDENSER INSPECTION

id071100801300

1. Inspect the condenser for cracks, damage, and oil leakage.
  - If there is any malfunction, replace the condenser.
2. Visually inspect for bent fins for clogging of foreign material.
  - If any fins are clogged, remove the foreign material.
3. Visually inspect for bent fins.
  - If any fins are bent, use the end of a flathead screwdriver to straighten fins.