


<b>DTC P0192:00</b>	<b>Fuel pressure sensor circuit low input</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>If the input voltage at the PCM terminal 1CA is <b>less than 0.156 V for 5 s</b>, the PCM determines that the fuel pressure sensor circuit is low.</li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>The DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>Stops the high pressure fuel pump control.</li> <li>Limits the intake air amount.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>Fuel pressure sensor connector or terminals malfunction</li> <li>Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> <li>Fuel pressure sensor terminal C—PCM terminal 1BJ</li> <li>Fuel pressure sensor terminal B—PCM terminal 1CA</li> </ul> </li> <li>PCM connector or terminals malfunction</li> <li>Fuel pressure sensor signal circuit and ground circuit are shorted to each other</li> <li>Fuel pressure sensor malfunction</li> <li>PCM malfunction</li> </ul>



## Diagnostic Procedure

STEP	INSPECTION	ACTION	
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.

STEP	INSPECTION		ACTION
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>• Verify related Service Information availability.</li> <li>• Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
3	<b>INSPECT FUEL PRESSURE SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition to off.</li> <li>• Disconnect the fuel pressure sensor connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	<b>INSPECT FUEL PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the fuel pressure sensor connector is disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— Fuel pressure sensor terminal C</li> <li>— Fuel pressure sensor terminal B</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness for a possible short to ground.</li> </ul> If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> <li>• Replace the PCM (short to ground in the PCM internal circuit).</li> </ul> (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 8.
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
6	<b>INSPECT FUEL PRESSURE SENSOR SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>• Verify that the fuel pressure sensor and PCM connectors are disconnected.</li> <li>• Inspect for continuity between fuel pressure sensor terminals B and A (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 8.
		No	Go to the next step.
7	<b>INSPECT FUEL PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>• Reconnect all disconnected connectors.</li> <li>• Inspect the fuel pressure sensor.</li> </ul> (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction?	Yes	Replace the fuel distributor, then go to the next step.
		No	Go to the next step.
8	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Make sure to reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS.</li> </ul> (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Start the engine. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM.</li> </ul> (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
9	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE".</li> </ul> (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection.
		No	DTC troubleshooting completed.