

**BSM OFF INDICATOR LIGHT ILLUMINATES CONTINUOUSLY [BLIND SPOT MONITORING (BSM)]**

id0903d9015200

<b>Description</b>	<b>BSM OFF indicator light illuminates continuously</b> <ul style="list-style-type: none"><li>• The BSM OFF indicator light illuminates for 4 s or more without the BSM OFF switch turning off after the ignition switch is turned to the ON position.</li></ul>
<b>Possible Causes</b>	<ul style="list-style-type: none"><li>• Malfunction in BSM OFF switch related parts<ul style="list-style-type: none"><li>— BSM OFF switch malfunction (stuck at on)</li></ul></li><li>• Instrument cluster does not turn off BSM indicator light<ul style="list-style-type: none"><li>— BSM control module (RH) malfunction</li><li>— Instrument cluster malfunction</li></ul></li></ul>

**Diagnostic Procedure**

<b>Step</b>	<b>Inspection</b>	<b>Result</b>	<b>Action</b>
1	<b>INSPECT IF MALFUNCTION IS IN BSM OFF SWITCH OR INSTRUMENT CLUSTER</b> <ul style="list-style-type: none"><li>• Monitor the BSM control module (RH) PID BSM_OFF_IL using the M-MDS. (See PID/DATA MONITOR INSPECTION [BLIND SPOT MONITORING (BSM)].)</li><li>• Turn the BSM OFF switch on and off.</li><li>• Does the PID BSM_OFF_IL monitoring value turn on and off according to the BSM OFF switch operation?</li></ul>	Yes	Go to Step 3.
		No	Go to the next step.
2	<b>INSPECT BSM OFF SWITCH</b> <ul style="list-style-type: none"><li>• Inspect the BSM OFF switch. (See BLIND SPOT MONITORING (BSM) OFF SWITCH INSPECTION.)</li><li>• Is the BSM OFF switch normal?</li></ul>	Yes	Go to the next step.
		No	Replace the BSM OFF switch. (See BLIND SPOT MONITORING (BSM) OFF SWITCH REMOVAL/INSTALLATION.)
3	<b>INSPECT IF MALFUNCTION IS IN INSTRUMENT CLUSTER OR BSM CONTROL MODULE (RH)</b> <ul style="list-style-type: none"><li>• Turn off the BSM OFF indicator light using the M-MDS instrument cluster active command modes WL+IL. (See ACTIVE COMMAND MODES INSPECTION [INSTRUMENT CLUSTER].)</li><li>• Does the BSM OFF indicator light turn off according to the active command modes?</li></ul>	Yes	Replace the BSM control module (RH). (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Replace the instrument cluster. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)