



DTC P0108:00	MAP sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the input voltage from the MAP sensor. If the input voltage at the PCM terminal 1BW is above 4.89 V for 5 s, the PCM determines that the MAP sensor circuit has a malfunction. <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Estimates MAP using MAF sensor and engine speed. Restricts the upper limit of the engine speed. Inhibits the evaporative purge control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> MAP sensor/IAT sensor No.2 connector or terminals malfunction PCM connector or terminals malfunction MAP sensor malfunction Short to power supply in wiring harness between MAP sensor/IAT sensor No.2 terminal D and PCM terminal 1BW Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> MAP sensor/IAT sensor No.2 terminal C—PCM terminal 1BO MAP sensor/IAT sensor No.2 terminal D—PCM terminal 1BW MAP sensor/IAT sensor No.2 terminal A—PCM terminal 1BX PCM malfunction



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	DETERMINE IF MAP SENSOR OR WIRING HARNESS MALFUNCTION <ul style="list-style-type: none"> Access the MAP PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Verify the MAP PID value. Is the MAP PID value 5 V or B+? 	Yes	When the voltage is 5 V <ul style="list-style-type: none"> Go to Step 7. When the voltage is B+ <ul style="list-style-type: none"> Go to Step 8.
		No	Go to the next step.
4	INSPECT MAP SENSOR/IAT SENSOR NO.2 CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the MAP sensor/IAT sensor No.2 connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	INSPECT MAP SENSOR <ul style="list-style-type: none"> Reconnect all disconnected connectors. Inspect the MAP sensor. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Is there any malfunction? 	Yes	Replace the MAP sensor/IAT sensor No.2, then go to Step 9. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to Step 9.
7	INSPECT MAP SENSOR/IAT SENSOR NO.2 CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Switch the ignition off. Disconnect the MAP sensor/IAT sensor No.2 connector and PCM connector. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> MAP sensor/IAT sensor No.2 terminal C—PCM terminal 1BO MAP sensor/IAT sensor No.2 terminal D—PCM terminal 1BW MAP sensor/IAT sensor No.2 terminal A—PCM terminal 1BX Is there continuity? 	Yes	Replace the MAP sensor/IAT sensor No.2, then go to Step 9. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT MAP SENSOR/IAT SENSOR NO.2 CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Switch the ignition off. Disconnect the MAP sensor/IAT sensor No.2 connector and PCM connector. Measure the voltage at the MAP sensor/IAT sensor No.2 terminal D (wiring harness-side). Is there any voltage? 	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to the next step.
		No	Replace the MAP sensor/IAT sensor No.2, then go to the next step. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)

STEP	INSPECTION		ACTION
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Start the engine and warm it up completely. • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	DTC troubleshooting completed.